



1. Place Black Washer on the Carriage Bolt.
2. Slide the Carriage Bolt through the slots of the inner and outer legs of the stand from the inside.
3. Place the White Washer over the threaded end of the bolt.
4. Thread the Knob onto the bolt to tighten.
5. Repeat the process for the other side.

